


Anziehvorschrift für Zylinderkopf		541.772	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a GM		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
Anziehen/ Tightening/ Serrage/ Apriete	* M12 Pos. 1-18: 50 Nm Pos. 1-18: 80 Nm ➤ Pos. 1-18: 60° ➤ Pos. 1-18: 60°	M8 Pos. 19-22: 25 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 105,36 mm; $\frac{1}{2}$: 1,05 mm; RH				
Mot: V8 Duramax 6.6 ltr.				
GMT 900, 610, 560				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*541.772*	