



<b>Anziehvorschrift für Zylinderkopf</b>	<b>541.782</b>		
<b>Tightening Instructions for Cylinder Head</b>			passend für / suitable for
<b>Instructions de serrage pour culasse</b>			adaptable à / adaptable a
<b>Prescripciones de apriete para culatas</b>			<b>GM</b>

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



Anziehen/ Tightening/ Serrage/ Apriete	* M12 Pos. 1-18: 50 Nm Pos. 1-18: 80 Nm	M8 Pos. 19-22: 25 Nm
	➤ Pos. 1-18: 60°	
	➤ Pos. 1-18: 60°	

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Ø: 105,36 mm; ɸ: 0,95 mm; LH

Mot: V8 Duramax  
6.6 ltr.

GMT 900, 610, 560

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*541.782\***