



Anziehvorschrift für Zylinderkopf	685.662	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



325.930
M 10x1,5x117



Anziehen/ Tightening/ Serrage/ Apriete	M10 * 40 Nm ➤ 90° ➤ 90°	M6 4 Nm 90°
---	----------------------------------	-------------------

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø 83,3 mm ± 0,9 mm

88-155 KW (120-211 PS)

Mot. BZB, BYT, BZB, CGYA, CAWA, CAWB, CCTA, CDAA, CDNC
CDNB, CAEB, CAEA, CBFA, CCZA, CCZB, CCTB, CABB, CABA
CDHA, CDHB, CABD, CFPA, CFKA, CDAB, CDMD, CESA, CETA

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

685.662