

Anziehvorschrift für Zylinderkopf		844.230		
Tightening Instructions for Cylinder Head		passend für / suitable for		
Instructions de serrage pour culasse		adaptable à / adaptable a		
Prescripciones de apriete para culatas		Toyota		
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Das Original		
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
13 9 6 2 3 7 12 12 8 4 1 5 10 14				
Anziehen/ Tightening/ Serrage/ Apriete				
* 35 Nm ➤ 90° ➤ 90°				
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*844.230*	