


<b>Anziehvorschrift für Zylinderkopf</b>	<b>153.142</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
passend für / suitable for adaptable à / adaptable a		<b>PSA, Fiat, Ford, Volvo</b>

Schraubenkopf / Head shape  
Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



267.550  
M 12x1,5x126



Anziehen/ Tightening/ Serrage/ Apriete	PSA DW10ATED4 * 20 Nm 60 Nm <input type="checkbox"/> 60 Nm ➤ 110° ➤ 110°	PSA DW12TED4 * 20 Nm 60 Nm <input type="checkbox"/> 20 Nm 60 Nm ➤ 110° ➤ 110°	Fiat, Ford, Volvo * 30 Nm 60 Nm ➤ 220°
---	---	---	---

Zeichenerklärung / Explanations / Explication / Explicacion

* ★ <input type="checkbox"/> ● ➤	neue Zylinderkopfschrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
--	--	---	---	--

**Motortyp / Engine type / Type de moteur / Tipo de motor**

✚ 1,35 mm, Ø 86 mm, 3 Löcher/holes/trous/agujeros

Mot.: G6DA, G6DB, G6DC, G6DD, G6DE, G6DF, AZWA  
QXWA, QXWB, DW10ATED4, DW10BTED4, DW12TED4  
RHR, RHK/DW10UTED4, D4202T/T2

Focus, C-Max / 307, 406, 407, 607, 807  
V40II, V50 / C4, C5, C8

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*153.142\***