



<b>Anziehvorschrift für Zylinderkopf</b>	<b>471.740</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
passend für / suitable for adaptable à / adaptable a	<b>Chevrolet/Daewoo</b>	

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



356.390  
M10x1,25x166



Anziehen/ \*    Pos. 1-10: 25 Nm  
Tightening/ ➤    Pos. 1-10: 70°  
Serrage/ ➤      Pos. 1-10: 70°  
Apriete    ➤      Pos. 1-10: 50°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Ø: 80 mm;  $\pm$ : 0,55 mm

Mot: F14D3, F16D3  
1.4 ltr-1.6 ltr

Chevrolet Aveo, Cruze, Kalos, Lacetti, Nubira  
Daewoo Kalos, Lacetti, Nubira

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*471.740\***