



| | | |
|--|---|---|
| Anziehvorschrift für Zylinderkopf | 493.062 |  |
| Tightening Instructions for Cylinder Head | | |
| Instructions de serrage pour culasse | | |
| Prescripciones de apriete para culatas | | |
| | passend für / suitable for adaptable à / adaptable a | AUDI |
| | | Das Original |

Schraubenkopf / Head shape
Tête de vis / Cabeza de tornillo



005.610
M 10x1,5x117

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



| | | | |
|-------------|---|-------|------|
| Anziehen/ | * | 10 Nm | 1-12 |
| Tightening/ | | 40 Nm | 1-12 |
| Serrage/ | ➤ | 90° | 1-12 |
| Apriete | ➤ | 90° | 1-12 |
| | * | 8 Nm | 13 |
| | ➤ | 90° | 13 |

Zeichenerklärung / Explanations / Explication / Explicacion

| | | | | |
|---|---|------------------------------|--------------------------------|---------------------------------------|
| * | neue Zylinderkopfschrauben verwenden | use new cylinder head bolts | utiliser des vis neuves | emplar tornillos nuevos |
| ★ | Warmlauf (80°C) | warm up time (80°C) | chauffage (80°C) | calentamiento (80°C) |
| □ | Schrauben einzeln lösen und wieder anziehen | loosen and tighten each bolt | deserrer et serrer vis par vis | aflojar y apretar tornillo a tornillo |
| ● | Setzzeit | relaxation time | durée de tassement | tiempo de espera |
| ➤ | Drehwinkel | torque angle | angle de serrage | ángulo de giro |

Motortyp / Engine type / Type de moteur / Tipo de motor

Mot. CEPA, CFPB

2,5 Ltr.
250,265 kW (340,360 PS)

Audi RS3, TTRS

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

493.062