



Anziehvorschrift für Zylinderkopf		649.280 passend für / suitable for adaptable à / adaptable a Subaru	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
Anziehen/ Tightening/ Serrage/ Apriete	* -> MY 2009 29 Nm 69 Nm ➤ losen 180° ➤ losen 180° 49 Nm ➤ 80° - 90° ➤ 40° - 45° ➤ only bolt 1&2: 45°	* MY 2010 -> Step 1-5: 40 Nm 95 Nm ➤ losen 180° ➤ losen 180° 10 Nm	* MY 2010 -> Step 5-10: 30 Nm 70 Nm ➤ 80° - 90° ➤ 40° - 45° ➤ only bolt 1&2: 45°	
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 93,5 mm; $\frac{1}{2}$: 0,6 mm				
Mot: EJ20X/Y; EJ204; EJ205 2.0 ltr. 16V Boxer				
2006 → Forester, Exiga, Legacy, Liberty, Impreza				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*649.280*	