

Einbauanleitung
 Fitting instructions
 Istruzioni di montaggio
 Notice de montage
 Instrucciones de montaje
 Monteringsanvisning

Audi A1	08.10 →
Seat Ibiza V	05.09 →
Seat Toledo	10.12 →
Skoda Fabia II	02.10 →
Skoda Praktik	06.07 →
Skoda Rapid	10.12 →
Skoda Roomster	02.10 →
VW Polo	01.09 →



The Perfect Change.

80001784 / 80001783
 CC1436 / CP1436
 MC 900 / MP 400

