

Solution

All you need for professional repairs!

Control arm including fitting materials



SWAG no. 50 93 7000
Repl. no. 1 064 128 S1

Fits:

All models of the Ford Focus 1 (1998-2004) except for RS/ST170

Problems may arise when replacing the rear control arm (SWAG no. 50 93 2582) due to severe corrosion between the rubber mounts and the mounting bolts. Often the only way to sever the connection is by destroying the bolts. As a result, it is necessary to replace the nuts and bolts as well. However, the control arm is frequently supplied by the manufacturer without the necessary fitting materials.

SWAG has the solution for a timely and efficient repair:

SWAG now also supplies these control arms as a Kit with the appropriate nuts and bolts (SWAG no. 50 93 7000).

**Note!**

The eccentric bolt and eccentric washer are used to set the camber which is absolutely imperative after replacing the control arm.

This complete repair kit enables a professional repair without the need for additional sourcing trips. That saves time and money for both workshop and customer!

Anyone using a Kit can safely assume that it contains all the parts necessary for the repair. Discover the new complete repair kits at: www.swag.de

SWAG also supplies all the components in the set separately.

**Simply ask for spare parts by SWAG.
The complete range can be found at: www.swag.de**