

FITTING INSTRUCTIONS  
 EINBAUANLEITUNG  
 INSTRUCCIONES DE MONTAJE  
 NOTICE DE MONTAGE  
 ISTRUZIONI DI MONTAGGIO  
 INSTRUKCJA MONTAŻU  
 INSTRUÇÕES DE MONTAGEM  
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

**micronAir®**

BMW 1	M Coupé	04.11 ->	80000063
BMW 1	E87	09.04 ->	CP1154
BMW 3er Series	E90 / E91	03.05 -> 09.13	MP195
BMW X1	E84	10.09 ->	80000064
			CC1154
			MC695
			49408596
			CB1154
			BL695

