

FITTING INSTRUCTIONS  
 EINBAUANLEITUNG  
 INSTRUCCIONES DE MONTAJE  
 NOTICE DE MONTAGE  
 INSTRUZIONI DI MONTAGGIO  
 INSTRUKCJA MONTAŻU  
 INSTRUÇÕES DE MONTAGEM  
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

**micronAir®**

<b>MCC</b>				
Smart	Fortwo		80005281	
Coupe	453	01.17 ->	CP1512	MP471
<b>Renault</b>			80005282	
Twingo	III	09.16 ->	CC1512	MC971
			49408805	
			CB1512	
			BL971	

