

Anziehvorschrift für Zylinderkopf		766.540 passend für / suitable for adaptable à / adaptable a Opel/GM	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
⑩ ⑥ ② ③ ⑦ ⑨ ⑤ ① ④ ⑧				
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	15 Nm 30 Nm 100° 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Opel Mot.: A20NHT (LTG) 1998ccm Insignia A 2.0 Turbo Insignia A 2.0 Turbo 4x4 Insignia A Sports Tourer 2.0 Turbo / 4x4 Insignia A Stufenheck 2.0 Turbo / 4x4				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*766.540*	