

NEW PRODUCT HIGHLIGHT | JUL2021



Blue Print ADN16847

To Fit:

Nissan Juke (F15), March 3, Micra
(K12), Note (E11), NP200 (U90)



EN

Fuel pump with fuel level sender unit

Function

A combined fuel pump, filter and fuel level sensor assembly are situated in the fuel tank. The fuel is pumped via an electric pump through the fuel filter to the engine fuel injection system.

Cause of failure

The engine not starting, stalling or poor performance, can be one of the indicators that the fuel pump is faulty. This is due to low or no fuel pressure. The engine warning light may also be on and diagnostic trouble code P0087, "Fuel Rail/System Pressure - Too Low", or P0088, "Fuel Rail/System Pressure - Too High", which are stored in the engine control unit.

For more technical information please visit: partsfinder.bilsteingroup.com