

INSTALLATION INTRUCTIONS - SMART BRAKE LIGHT SWITCH

1. Press the brake pedal to increase the distance between the pedal lever and the holder of the brake light switch.
2. Place a feeler gauge (3.6mm thick) between the brake pedal and the switch.
3. Pull the tappet of the brake light switch to the stop.
4. Install the switch with the inserted feeler gauge.
5. Release the brake pedal slowly to allow the free travel of the brake light switch to adjust itself automatically.
6. Remove the feeler gauge.
7. Check the adjustment:
 - a. Attatch a tape measure to the brake pedal and connect it to the steering wheel.
 - b. Check the figure on the tape measure with the brake pedal released.
 - c. Press the brake pedal until the brake lights illuminate and read the second figure on the tape measure: The brake pedal travel must be between 7 and 12mm. If the distance is greater, repeat the complete installation process with a thicker feeler gauge (4.2mm, 5mm).
8. Delete error memory if necessary and check the correct functioning.

